

Handling Precautions for TOLI NW Series

* This product is part of the TOLI NW (NO WAX) series.

① Please handle the product with care.

If the product is subjected to a strong impact, it may crack, dent, or damage the product.

② If the product is installed at a low temperature and the Sheet needs to be heated, please heat it slowly so that the surface temperature reaches 30-40°C.

* Accelerated heating may cause discoloration or warping of the flooring.

③ Cut the welding rod while it is still warm.

④ Use a mop or similar tool to remove dust caused by the installation process.

Wash the mop frequently to remove any dirt that may have adhered to the mop.

If dirt remains on the floor, use a cleaning solution and clean it with a polisher or automatic floor washer.

To find additional information, including maintenance guide,
please visit the TOLI Global website.

TOLI Corporation Global

 search

